# 7-Step
Assembly Instructions

PARTS - Component A & B

Prior to assembly, orient the wood components using the diagram pictured below.

For example, for horizontal components, letters will be on TOP facing toward the front.

For vertical components, letters will be on the RIGHT side in vertical orientation.

A16

A12

B7

A15

A11

A10

A9

B6

B5

A8

A14

B2

B3

A5

A6

B4

A13

A7

A4

A3

A2

B1

A1

Component A

Component B

| 2x	1x	18x

STEP
01

The cabienos must be align with a receiving hole

Apply wood glue to the edges of the wood that will make contact with each other.

GLUE

A1
A2
A3
A4
A5

# STEP
02

A6
A7

STEP 03

A8

STEP 04

A9

A10

STEP 05

A11

STEP 06

A12

A11

STEP
## 07


A16
A15
A14
A13

STEP
08

B2
B3
B1

STEP
09

STEP
## 10

STEP
11

Bolt Components A & B together.

*** Holes are predrilled for your convenience.

PARTS - Component C & E

Prior to assembly, orient the wood components using the diagram pictured below.

For example, for horizontal components, letters will be on TOP facing toward the front.

For vertical components, letters will be on the RIGHT side in vertical orientation.

Component E

Component C

STEP
01

The cabienos must be align with a receiving hole

GLUE

Apply wood glue to the edges of the wood that will make contact with each other.

C2

C3

C1

STEP
02

C6

C5

C4

STEP
03

STEP
04

STEP
05

STEP
06

STEP
07

E2

E3

E1

STEP
08

E7

E6

E5

E4

STEP
09

STEP
10

STEP
11

STEP
12

Bolt Components C & E together.

STEP
13

Bolt Components B & C/E together.

*** Holes are predrilled for your convenience.

FINISH

Use the diagram for cabinet door placement.

1. Match the number/letter indicated in the hinge pocket of the cabinet door to the diagram.
2. Screw hinges into cabinet door, then secure inside of staircase. Hinge placement indicated with 'X'.

Installation Note:

For the safest and most secure setup, we recommend professional installation.

Use a stud finder to locate studs and drill through each triangle gusset, securing it to as many studs as possible. If the baseboard prevents the staircase from sitting flush against the wall, remove it before installation.